

Model 200 Floor Sentry Double

Model # SS-200-FSD

Multi-Operator

Product Specifications

BASE UNIT DIMENSIONS

10.5" Length
8" Width
10.5" Height

ARM DIMENSIONS

(2) 3" Diameter x 52" Long (5" Round Hood)

CABINET MATERIAL

16 ga. Carbon Steel

WEIGHT

Approx. 12 lbs.

AIR VOLUME

Up to 100 CFM. *Varies with filter media.*

ELECTRICAL

115/1/60, Approx. 0.3 Amps
220/1/50, Approx. 0.2 Amps
8' grounded power cord with NEMA 5-15P Plug

SOUND LEVEL

Approx. 56 dba @ 2' from inlet

FILTRATION

Depending on the Application:

- HEPA [up to 99.97% efficient on particles 0.3 microns and larger]
- ASHRAE [up to 95% efficient on particles 0.5 microns and larger]
- ACTIVATED CARBON
- SPECIALTY-BLENDED FILTER MEDIA [i.e. Acid Gas, Mercury, Aldehyde, Ammonia]

WARRANTY

Limited two-year warranty from date of shipment on defects due to materials or workmanship.
PATENT #5,843,197



3" Diameter, 52" L Flex Arms

Dimensions are Approximate

Product Features

- Two Self-Supportive 52" L Flex Arms *Included*
- Quiet Operation
- Small Footprint
- Highly Portable and Lightweight
- Simple, Quick "No Tool" Filter Change
- Optional Variable Speed Controller (115V only)
- Reliable, Low Maintenance Operation
- Long Filter Life
- Optional Hour Counter

The **Floor Sentry Double** is uniquely designed to provide fume extraction to two operators simultaneously. The two self-supportive flex arms provide equal suction at both inlets, which directs contaminants into a patented filtration system that is customized depending on the application being performed. HEPA [up to 99.97% efficient on particles 0.3 microns and larger], ASHRAE [up to 95% efficient on particles 0.5 microns and larger], Activated Carbon, and specialty-blended filter media [i.e. Acid Gas, Mercury, Aldehyde, Ammonia] are the standard options for this unit. This unit can easily be placed on the floor to free up much needed workspace, or it can be placed on the benchtop itself.

Typical applications for this unit include soldering, chemical fumes, light grinding, solvent and epoxy fumes, dust, pharmaceutical powders and many other procedures that involve particulate and fume.

The **Floor Sentry Double** offers a highly energy-efficient, quiet, and economical solution to fume extraction for multiple operator use.

This unit is also available with a single arm [SS-200-FS] and with a more powerful fan and filtration system [SS-300-FSD & SS-400-FSD].



1.800.799.4609
www.sentryair.com
sales@sentryair.com

