

## Model 200 Table Sentry

### Model # SS-200-TS

#### Product Specifications

##### BASE UNIT DIMENSIONS

10.5" Length  
8" Width  
10.75" Height  
2.25" Slot

##### CABINET MATERIAL

16 ga. Carbon Steel

##### WEIGHT

Approx. 12 lbs.

##### AIR VOLUME

Up to 100 CFM. *Varies with filter media.*

##### ELECTRICAL

115/1/60, Approx. 0.3 Amps  
220/1/50, Approx. 0.2 Amps  
8' grounded power cord with NEMA 5-15P Plug

##### SOUND LEVEL

58 DBA at 3'

##### FILTRATION

Depending on the Application:

- HEPA [up to 99.97% efficient on particles 0.3 microns and larger]
- ASHRAE [up to 95% efficient on particles 0.5 microns and larger]
- ACTIVATED CARBON
- SPECIALTY-BLENDED FILTER MEDIA [i.e. Acid Gas, Mercury, Aldehyde, Ammonia]

##### WARRANTY

Limited two-year warranty from date of shipment on defects due to materials or workmanship.  
PATENT #5,843,197



Dimensions are Approximate

#### Product Features

- Quiet Operation
- Highly Portable and Lightweight
- Reliable, Low Maintenance Operation
- Low Power Consumption
- Simple, Quick "No Tool" Filter Change
- Long Filter Life
- Sturdy Construction
- Optional Variable Speed Controller (115V only)
- Optional Hour Counter

The **Table Sentry** is a compact fume extractor that is built specifically for stationary, benchtop operations where airborne fumes need to be captured and filtered at the work surface level. An optional adjustable height stand is available and is highly efficient for elevated operations such as solder pot applications.

Typical applications include soldering, light grinding, solvent and epoxy fumes, particulate, powder filling, solder pot fumes, and a variety of other applications involving chemical fumes and dust.

This system incorporates an energy-efficient fan and high-quality filtration media to capture and purify harmful particulate. The most common filters utilized in this unit are HEPA filtration [up to 99.97% efficient on particles 0.3 microns and larger], ASHRAE filtration [up to 95% efficient on particles 0.5 microns and larger], Activated Carbon, and specialty-blended filtration media [i.e. Acid Gas, Mercury, Aldehyde, Ammonia].

The **Table Sentry** fume extractor offers an effective, quiet and economical solution for many benchtop operations which require fume extraction.



1.800.799.4609  
[www.sentryair.com](http://www.sentryair.com)  
[sales@sentryair.com](mailto:sales@sentryair.com)

